


Tips for use CUBE



General

With the Quooker CUBE, you can dispense filtered chilled and sparkling water straight from your Quooker tap. Read the tips below to optimise your use of the CUBE. Also read the 'Tips for use' which you received with your Quooker tank for information about its use.




fig. 1

Tap operation

With a Quooker CUBE connected to your Quooker tank, you can easily switch between boiling, hot, cold, filtered chilled and sparkling water. Hot and cold water are dispensed by using the mixer handle. Boiling, filtered chilled and sparkling water are dispensed using the textured ring.

Boiling water (fig. 1)

Boiling water is dispensed by first pushing the textured ring down twice, then turning it anti-clockwise. The LED ring will light up red and stay red while boiling water is dispensed. In addition to this safety feature, the pull-out flexible hose on the Flex tap will immediately cut off the boiling water, if it is pulled out of the spout.




fig. 2

Filtered chilled water (fig. 2)

Press the textured ring down once and hold it down until the LED turns solid blue, then turn it anti-clockwise. Filtered chilled water will now be dispensed.




fig. 3

Filtered sparkling water (fig. 3)

To dispense sparkling water, press the textured ring down once, then turn it anti-clockwise immediately. The tap LED will now flash blue and keep flashing whilst sparkling water is dispensed.

Turn the ring back to close the tap. A small amount of water will continue to flow to ensure all sparkling water is flushed out of the tap spout.




fig. 4

First use (fig. 4)

Once the CUBE has been connected, flush the CUBE's filtered & sparkling water through twice for one minute each time (the tap switches off automatically after one minute). This will flush away any impurities there might be in the pipes. The sparkling water tank in the CUBE cools down within 60 minutes after installation. The exact length of time depends on the temperature of the inflowing water.



fig. 5

Changing the CO₂ cylinder (fig. 5)

When the flow of sparkling water becomes reduced and there are less bubbles in the water, the CO₂ cylinder should be replaced. When the CO₂ cylinder is completely empty, no water will come out when you try to dispense sparkling water.



fig. 6

Replace filters (fig. 6)

The CUBE is equipped with a hollow fibre filter. This filter ensures a better water quality because it filters bacteria from the water. For hygienic reasons, the filter should be replaced every twelve months, regardless of the amount of water used. After twelve months, the CUBE will start beeping and the light on the CUBE tank will flash to indicate that the filter needs to be replaced (fig. 7). The filter can be accessed under the sliding panel on top of the CUBE. Instructions for replacing the filter are printed on the filter cartridge.




fig. 7

Once the filter has been replaced, you can reset the timer for another twelve months. To do this, press & hold the red illuminated button under the sliding panel for five seconds. The CUBE will then beep and the red light will go out.

Maintenance

Clean the CUBE's ventilator fan once a year using a brush or vacuum cleaner. In addition, the CUBE's filter should be replaced annually. The CUBE will flash and beep to indicate when this should be done. Clear instructions for replacing the filter are printed on the filter cartridge. Replacement filters can be ordered via quooker.co.ae

Going on holiday? Turn off the CUBE and flush it through when you return

If you're going away for more than two weeks, we advise turning the CUBE off using the switch at the back of the CUBE or by turning off the power at the power socket. When returning home, it's important to flush the CUBE through by dispensing both chilled and sparkling water twice for one minute each time (the tap switches off automatically after one minute).

Malfunction

If the CUBE stops working correctly, please contact our service department on 0800-QUOOKER (7866537) or by e-mail: service@quooker.ae. Answers to frequently asked questions can be found on our website under Service: quooker.ae.

Warranty and service

The warranty period for the CUBE and Quooker system is two years and covers supply of parts only. It does not cover labour costs or any mechanical failure due to limescale. Only genuine Quooker parts should be used with a Quooker and use of any third party parts of any sort will void the warranty. Register your Quooker at Quooker.ae/aen/register-your-quooker.

Quooker®

Quooker Emirates LLC
Indigo Central 2, Al Safa 2
Sheik Zayad Road
Dubai (UAE)
0800 7866537
info@quooker.ae
quooker.ae